



NATIONAL AEROSPACE STANDARD (NAS) DRILLS

NAS 907 - Type C - HSS Screw Machine Drills

Styles:

R40C, R41C, R42C,
R40C & R41C Drill Sets



NAS 907 - Type A - HSS Jobber Drills

Styles:

R10A, R18A, R15A



NAS 907 - Type J - HSS Jobber Drills

Styles:

R10CO, R18CO, R15CO



NAS 907 - Type J - HSCO Aircraft Extension Drills

Styles:

CO500-6, CO501-6, CO500-12, CO501-12



NAS 907 - Type D - HSCO Heavy-Duty Jobber Drills

Styles:

R88CO, R89CO



NAS 907 - Type B - HSS Jobber Drills

Styles:

R10B, R18B, R15B



NAS 907 - Type B - HSS Aircraft Extension Drills

Styles:

500-6, 501-6, 502-6, 500-12, 501-12, 502-12
A243, A244



NAS 965 - Type B - HSS Threaded Hex Shank Drills

Styles:


TS10, TS18, TS15 - short
TS40, TS41 - stub
TS51, TS52, TS55 - long



HSS Aircraft Taper Router (Taper=1/4" per foot)

Styles:

ATR41



To learn more about NAS 907, NAS 937 and NAS 965 attributes please visit www.dormerpramet.com